



PRIUS

Gasoline-Electric Hybrid

*Emergency Response Guide
(Revised)*



Foreword

This guide was developed to educate and assist emergency responders in the safe handling of the Toyota Prius gasoline-electric hybrid vehicle following an incident. Prius emergency response procedures are similar to other Toyota vehicles with the exception of the high voltage electrical system. It is important to recognize and understand the high voltage electrical system features and specifications of the Toyota Prius as they may not be familiar to emergency responders.

High voltage electricity powers an electric motor, generator, and inverter. All other conventional automotive electrical devices such as the headlights, radio, and gauges are powered from a separate 12-Volt battery. Numerous safeguards have been designed into the Prius to help ensure the high voltage, approximately 274-Volt, Nickel Metal Hydride (NiMH) Hybrid Vehicle (HV) battery pack is kept safe and secure in an accident.

The NiMH HV battery pack contains sealed batteries that are similar to rechargeable batteries used in laptop computers, cell phones, and other consumer products. The electrolyte is absorbed in the cell plates and will not normally leak out even if the battery is cracked. In the unlikely event the electrolyte does leak, it can be easily neutralized with a dilute boric acid solution or vinegar.

High voltage cables, identifiable by orange insulation and connectors, are isolated from the metal chassis of the vehicle. These cables are routed underneath and inboard the floor pan reinforcement which would not normally be accessed by emergency responders at the scene of an accident.

Additional topics contained in the guide include:

- Toyota Prius identification.
- Major hybrid component locations and descriptions.
- Extrication, fire, recovery, and other emergency response information.
- Roadside assistance information.

By following the information in this guide, emergency responders will be able to handle the Prius hybrid-electric vehicle as safely as the emergency response of a conventional gasoline engine automobile.

Note:

*This **Prius Emergency Response Guide (Revised)** supercedes the earlier **Prius Emergency Response Guide** published by Toyota Motor Corporation in 2000 (Publication No OTH020U)*

(BLANK PAGE)

Table of Contents	Page
About the Prius	1
Prius Identification	3
Hybrid Component Locations & Descriptions	7
Gasoline-Electric Hybrid Vehicle Operation	9
Hybrid Vehicle (HV) Battery Pack and Auxiliary Battery	11
High Voltage Safety	13
SRS Airbags and Seat Belt Pretensioners	15
Emergency Response	17
Extrication	17
Fire	21
Overhaul	22
Recovery/Recycling NiMH HV Battery Pack	22
Spills	23
First Aid	23
Submersion	24
Roadside Assistance	25

About the Prius


The Toyota Prius is a gasoline-electric hybrid vehicle sold in North America since May 2000. Gasoline-electric hybrid means the vehicle contains a gasoline engine and an electric motor for power. Two energy sources are stored on board the vehicle:

1. Gasoline stored in the fuel tank for the gasoline engine.
2. Electricity stored in a high voltage Hybrid Vehicle (HV) battery pack for the electric motor.


The result of combining these two power sources is increased fuel economy and reduced emissions. The gasoline engine also powers an electric generator to recharge the battery pack; so, unlike a pure all electric vehicle, the Prius never needs to be recharged from an external electric power source.

Depending on the driving conditions one or both sources are used to power the vehicle. The following illustrations demonstrate how the Prius operates in various driving modes.

- ① On light acceleration at low speeds, the vehicle is powered by the electric motor. The gasoline engine is shut off.
- ② During normal driving the vehicle is powered mainly by the gasoline engine. The gasoline engine is also used to recharge the battery pack.



- ③ During full acceleration, such as climbing a hill, both the gasoline engine and the electric motor power the vehicle.
- ④ During deceleration, such as braking, the vehicle regenerates the kinetic energy from the front wheels to produce electricity that recharges the battery pack.
- ⑤ While the vehicle is stopped, the gasoline engine and electric motor are off, however the vehicle remains on and operational.





Prius Identification

In appearance, the Prius is similar to a compact 4-door sedan. Exterior, interior, and engine compartment illustrations are provided to assist in identification.

The alphanumeric 17 character Vehicle Identification Number (VIN) is provided in the front windshield cowl and driver door post.




Example VIN: JT2BK12U810020208

(A Prius is identified by the first 6 alphanumeric characters **JT2BK1**)



Exterior



- ❶ *TOYOTA Hybrid & PRIUS* logos on trunk.
- ❷ Gasoline fuel filler door located on passenger side quarter panel.
- ❸ HV battery pack air vent on the driver side C-pillar.
- ❹ Toyota logo on the hood.



Prius Identification (Continued)



Interior

- ⑤ Column mounted automatic transmission shift lever.
- ⑥ Instrument cluster (speedometer, fuel gauge, warning lights) located in center dash and near the base of the windshield.
- ⑦ LCD monitor (fuel consumption, radio controls) located below the instrument cluster.



Engine Compartment

- ⑧ 1.5 liter aluminum alloy gasoline engine.
- ⑨ High voltage inverter box with the *Toyota Hybrid System* logo on the cover.
- ⑩ Orange colored high voltage power cables.







Hybrid Component Locations & Descriptions

Component	Location	Description
12-Volt ❶ Auxiliary Battery	Trunk, Driver Side	Low voltage lead-acid battery that controls all electrical equipment except electric motor generator, and inverter.
Hybrid ❷ Vehicle (HV) Battery Pack	Trunk, Mounted to Cross Member & Behind Rear Seat	274-Volt Nickel Metal Hydride (NiMH) battery pack consisting of 38 low voltage (7.2-volt) modules connected in series.
Power ❸ Cables	Under Carriage & Engine Compartment	Orange colored power cables carry high voltage Direct Current (DC) between the HV battery pack and inverter. Also carries 3 phase Alternating Current (AC) between inverter, motor, and generator.
Inverter ❹	Engine Compartment	Converts DC electricity from HV battery pack to AC electricity that drives the electric motor. Also, converts AC from electric generator and motor (regenerative braking) to DC that recharges the HV battery pack.
Gasoline ❺ Engine	Engine Compartment	Provides two functions: 1) powers vehicle; 2) powers generator to recharge the HV battery pack. The engine is started and stopped under control of the vehicle computer.
Electric ❻ Motor	Engine Compartment	3 Phase AC permanent magnetic electric motor contained in the transaxle. Used to power the vehicle.
Electric ❼ Generator	Engine Compartment	3 Phase AC generator contained in the transaxle. Used to recharge the HV battery pack.
Fuel Tank ❸ and Fuel Lines	Undercarriage, Passenger Side	Fuel tank provides gasoline via a single fuel line to the engine. The fuel line is routed along passenger side under the floor pan.

Specifications

Gasoline Engine:	70 hp, 1.5 liter Aluminum Alloy Engine
Electric Motor:	44 hp, Permanent Magnet Motor
Transmission:	Automatic Only
HV Battery:	274-Volt Sealed NiMH
Curb Weight:	2,765 lbs
Fuel Tank:	11.9 gals
Fuel Economy:	52/45 (City/Hwy)
Frame Material:	Steel Unibody & Steel Body Panels




Gasoline-Electric Hybrid Vehicle Operation

The vehicle starts and becomes operational by turning the ignition key to start just like any other typical automobile. However, the gasoline engine does not idle like a typical automobile and will start and stop automatically. It is important to recognize and understand the **READY** indicator provided in the instrument cluster. When lit, it informs the driver the vehicle is on and operational even though the gasoline engine may be off and the engine compartment is silent.

Vehicle Operation

- With the Prius, the gasoline engine may stop and start at any time while the **READY** indicator is on.
- Never assume the vehicle is shut off just because the engine is off. Always look for the **READY** indicator status. The vehicle is shut off when the **READY** indicator is off.
- The vehicle may be powered by:
 1. The electric motor only.
 2. The gasoline engine only.
 3. A combination of both the electric motor and the gasoline engine.

The vehicle computer determines the mode in which the vehicle operates to improve fuel economy and reduce emissions. The driver cannot manually select the mode.



Hybrid Vehicle (HV) Battery Pack and Auxiliary Battery

The Prius contains a high voltage, Hybrid Vehicle (HV) battery pack and a low voltage auxiliary battery. The HV battery pack contains non-spillable, sealed Nickel Metal Hydride (NiMH) battery modules and the auxiliary battery is a typical automotive lead-acid type.

HV Battery Pack

- The HV battery pack is sealed in a metal case and is rigidly mounted to the trunk floor pan cross member behind the rear seat. The metal case is isolated from high voltage and concealed by a fabric liner in the trunk.
- The HV battery pack consists of 38 low voltage (7.2-Volt) NiMH battery modules connected in series to produce approximately 274-Volts. Each NiMH battery module is non-spillable and sealed in a plastic case.
- The electrolyte used in the NiMH battery module is an alkaline of potassium and sodium hydroxide. The electrolyte is absorbed into the battery cell plates and will form a gel that will not normally leak, even in a collision.
- In the unlikely event the battery pack is overcharged, the modules vent gases directly outside the vehicle through a vent hose connected to each NiMH battery module.

HV Battery Pack	
Battery pack voltage	274-Volts
Number of NiMH battery modules in the pack	38
Battery pack weight	100 lbs
NiMH battery module voltage	7.2-Volts
NiMH battery module dimensions (inches)	11 x 3/4 x 4
NiMH Battery module weight	2.2 lbs

Components Powered by the HV Battery Pack



- Electric Motor
- Electric Generator
- Inverter
- Power Cables

HV Battery Pack Recycling

- The HV battery pack is recyclable. Contact the nearest Toyota dealer, or:
United States: (800) 331-4331 Canada: (888) Toyota-8

Auxiliary Battery

- The Prius also contains a lead-acid 12-Volt battery. This 12-Volt auxiliary battery powers the vehicle electrical system similar to a conventional vehicle. As with other conventional vehicles, the auxiliary battery is grounded to the metal chassis of the vehicle.
- The auxiliary battery is located in the trunk. It also contains a hose to vent gases outside the vehicle if overcharged.



High Voltage Safety

The HV battery pack powers the high voltage electrical system with direct current (DC) electricity. A positive and a negative power cable are routed from the battery pack, under the vehicle floor pan, to the inverter. Occupants in the vehicle and emergency responders are separated from high voltage electricity by the following systems:



High Voltage Safety System

- A high voltage fuse ❶ provides short circuit protection in the HV battery pack.
- The positive and negative power cables ❷ connected to the HV battery pack are controlled by 12-Volt normally open relays ❸. When the vehicle is shut off, the relays stop electricity flow from the HV battery pack.

WARNING:

- *Power remains in the high voltage electrical system for 5 minutes after the HV battery pack is shut off.*
- *Never touch, cut, or open any high voltage power cable or high voltage component.*

- Both power cables ❷ are isolated from the metal chassis, so there is no possibility of shock by touching the metal chassis.
- A ground fault monitor ❹ continuously monitors for high voltage leakage to the metal chassis while the vehicle is running. If a malfunction is detected, the vehicle computer ❺ will illuminate the master warning light in the instrument cluster and the hybrid warning light in the LCD display.
- The HV battery pack relays will automatically open to stop electricity flow in a collision sufficient to activate the front SRS airbags.




SRS Airbags and Seat Belt Pretensioners


The Prius includes as standard equipment driver and passenger front SRS airbags and front seat belt pretensioners. Side impact SRS airbags contained in the front seats are optional equipment.

The SRS system is equipped with a back up source that powers the SRS airbags up to **90 seconds** after disconnecting the 12-Volt auxiliary battery.


Airbag and Sensor Locations

- Two front SRS airbag sensors ❶ are mounted in the engine compartment for the driver ❷ and passenger ❸ airbags.
- The SRS computer ❹, which also contains a sensor, is mounted on the floor pan near the center console.
- Front seat pretensioners are mounted in the B-pillar ❺.
- Optional side impact SRS airbags are contained in the front seats ❻. The sensors are mounted in the B-pillar ❼.






Front Seat Airbag Components



Front Seat Belt Pretensioner Components



Front Seat Side Airbag Components

Emergency Response

On arrival, emergency responders should follow their standard operating procedures for vehicle incidents. Emergencies involving the Prius may be handled like other automobiles except as noted in these guidelines for Extrication, Fire, Overhaul, Recovery, Spills, First Aid, and Submersion.

WARNING:

- *Never assume the Prius is shut off simply because it is silent.*
- *Always observe the instrument cluster for the **READY** indicator status to verify whether the vehicle is on or shut off.*

Extrication


- Immobilize Vehicle
Chock wheels and set the parking brake.
Move the shift lever to the **P** (park) position.
- Disable Vehicle (HV battery pack, SRS airbags, & gasoline fuel pump)
Turn the ignition key off, remove the ignition key, and place on dash.
Disconnect 12-Volt auxiliary battery.

-OR (if the ignition key is inaccessible)-


Disconnect the 12-Volt auxiliary battery.
Remove the IGCT relay in the engine compartment as shown in the illustration.

WARNING:


- *After disabling the vehicle, power is maintained for **90 seconds** in the SRS system and **5 minutes** in the high voltage electrical system.*
- *If either of the disabling steps above cannot be performed, proceed with caution as there is no assurance that the high voltage electrical system, SRS, or fuel pump are disabled.*
- *Never touch, cut, or open any orange high voltage power cable or high voltage component.*




Chock Wheels




Set Parking Brake




Move Shift Lever To Park




Remote Trunk Opener (Driver Side)




12-Volt Auxiliary Battery Cover



Remote Hood Release



Hood Latch Release



IGCT Relay Location

Emergency Response (Continued)

Extrication (Continued)

- Stabilize Vehicle

Crib at (4) points directly under the front and rear pillars.
Do not place cribbing under the high voltage power cables, exhaust system, or fuel tank.

- Access Patients

Glass Removal

Use normal glass removal procedures as required.

Door Removal/Displacement

Doors can be removed by conventional rescue tools- hand, electric, and hydraulic.

In certain situations, it may be easier to pry back the body to expose and unbolt the hinges.

Dash Displacement

Displace the dash by using a conventional dash roll, Modified Dash Roll, or jacking the dash.

Roof Removal


The roof may be removed as there are no SRS airbag devices above the door line.

Rescue Lift Air Bags


Responders should not place rescue lift airbags under the high voltage power cables, exhaust system, or fuel tank.

Steering and Seat Controls

Tilt steering and seat controls are shown in the illustration.



Cribbing Points



Tilt Steering Control

Front Seat Controls

Emergency Response (Continued)

Fire

Approach and extinguish a fire using proper vehicle fire fighting practices as recommended by NFPA, IFSTA, or the National Fire Academy (USA).

- Extinguishing Agent
Water has been proven to be a suitable extinguishing agent.
- Initial Fire Attack
Perform a fast, aggressive fire attack.
Divert the runoff from entering watershed areas.

Attack teams may not be able to identify a Prius until the fire has been knocked down and overhaul operations have commenced.
- Fire in the HV Battery Pack
Should a fire occur in the NiMH HV battery pack, the incident commander will have to decide whether to pursue an offensive or defensive attack.

WARNING:

- *Potassium hydroxide and sodium hydroxide are key ingredients in the NiMH battery module electrolyte.*
- *The modules are contained within a metal case and access is limited to a small opening on the top.*
- *The cover should **Never** be breached or removed under any circumstances, including fire. Doing so may result in severe electrical burns, shock or electrocution.*

When allowed to burn themselves out, the Prius NiMH battery modules burn rapidly and can quickly be reduced to ashes except for the metal alloy cell plates.

Offensive Fire Attack

Flooding the HV battery pack, located in the trunk, with copious amounts of water at a safe distance will effectively control the HV battery pack fire by cooling the adjacent NiMH battery modules to a point below their ignition temperature. The remaining modules on fire, if not extinguished by the water, will burn themselves out.

Defensive Fire Attack

If the decision has been made to fight the fire using a defensive attack, the fire attack crew should pull back a safe distance and allow the NiMH battery modules to burn themselves out. During this defensive operation, fire crews may utilize a water stream or fog pattern to protect exposures or to control the path of smoke.

Overhaul

During overhaul, if not already done, immobilize and disable the vehicle. See illustrations on page 18.

- Immobilize Vehicle
Chock wheels and set the parking brake.
Move the shift lever to the **P** (park) position.
- Disable Vehicle (HV battery pack, SRS airbags, & gasoline fuel pump)
Turn the ignition key off, remove the ignition key, and place on dash.
Disconnect 12-Volt auxiliary battery.

-OR (if the ignition key is inaccessible)-

Disconnect the 12-Volt auxiliary battery.
Remove the IGCT relay in the engine compartment.

WARNING:

- *After disabling the vehicle, power is maintained for **90 seconds** in the SRS system and **5 minutes** in the high voltage electrical system.*
- *If either of the disabling steps above cannot be performed, proceed with caution as there is no assurance that the high voltage electrical system, SRS, or fuel pump are disabled.*
- ***Never** touch, cut, or open any orange high voltage power cable or high voltage component.*

Recovery/Recycling NiMH HV Battery Pack

Clean up of the HV battery pack can be accomplished by the vehicle recovery crew without further concern from runoff or spill. For information regarding recycling of the HV battery pack, contact the nearest Toyota dealer, or:

United States: (800) 331-4331 Canada: (888) Toyota-8

Emergency Response (Continued)

Spills

The Prius contains the same common automotive fluids used in other Toyota vehicles, with the exception of NiMH electrolyte used in HV battery pack. The NiMH battery electrolyte is a caustic alkaline (pH 13.5) that is damaging to human tissues. The electrolyte, however, is absorbed in the cell plates and will not normally spill or leak out even if a battery module is cracked. A catastrophic crash that would breach both the metal battery pack case and the plastic battery module would be a rare occurrence.

Similar to using baking soda to neutralize a lead-acid battery electrolyte spill, a dilute boric acid solution or vinegar is used to neutralize a NiMH battery electrolyte spill.

During an emergency, Toyota Material Safety Data Sheets (MSDS) may be requested by contacting:

United States: CHEMTREC at (800) 424-9300

Canada: CANUTEC at *666 or (613) 996-6666 (collect)

- Handle NiMH Electrolyte Spills Using The Following Personal Protective Equipment (PPE):
 - Splash shield or safety goggles. Fold down helmet shields are not acceptable for alkaline spills.
 - Rubber, latex or Nitrile gloves.
 - Apron suitable for alkaline.
 - Rubber boots.
- Neutralize NiMH Electrolyte
 - Use a boric acid solution or vinegar.
 - Boric acid solution - 800 grams boric acid to 20 liters water or 5.5 ounces boric acid to 1 gallon of water.

First Aid

Emergency responders may not be familiar with a NiMH electrolyte exposure when rendering aid to a patient. Exposure to the electrolyte is unlikely except in a catastrophic crash or through improper handling. Utilize the following guidelines during an exposure.

WARNING:

The NIMH battery electrolyte is a caustic alkaline (pH 13.5) that is damaging to human tissue.

- **Wear Personal Protective Equipment (PPE)**
 Splash shield or safety goggles. Fold down helmet shields are not acceptable for acid or alkaline spills.
 Rubber, latex or Nitrile gloves.
 Apron suitable for alkaline.
 Rubber boots.
- **Absorption**
 Perform gross decontamination by removing affected clothing and properly disposing of the garments.
 Rinse the affected areas with water for 20 minutes.
 Transport to the nearest emergency medical care facility.
- **Inhalation Non-Fire Situations**
 No toxic gases are emitted under normal conditions.
- **Inhalation Fire Situations**
 Toxic gases are given off as the by-product of combustion. All responders in the Hot Zone should wear the proper PPE for fire fighting including SCBA.
 Remove patient from the hazardous environment to a safe area and administer oxygen.
 Transport to the nearest emergency medical care facility.
- **Ingestion**
 Do not induce vomiting.
 Allow patient to drink large quantities of water to dilute electrolyte (Never give water to an unconscious person).
 If vomiting occurs spontaneously, keep patients head lowered and forward to reduce the risk of aspiration.
 Transport to the nearest emergency medical care facility.

Submersion

To safely handle a Prius that is fully or partially submerged in water, disable the high voltage electrical system and SRS airbags.

- Remove vehicle from the water.
- Drain water from the vehicle if possible.
- Follow the extrication and vehicle disabling procedure (page 17).

Roadside Assistance

No special or unusual handling is necessary for Prius roadside assistance. The vehicle may be handled like other Toyota vehicles and the following information may be useful for guidance.

Toyota Roadside Assistance is available during the basic warranty period by contacting:

United States: (877) 304-6495 Canada: (888) TOYOTA-8

Towing

The Prius is a front wheel drive vehicle. Tow with the front wheels off the ground.

- To shift the vehicle to neutral, turn the ignition switch on, press the brake, and while pressing the shift lever button, move the lever to the **N** (neutral) position.
- If the shift lever cannot be moved out of **P** (park), a shift lock release is provided under the steering column cover as shown in the illustration.

Spare Tire

The spare tire, jack, and tools are provided in the trunk as shown in the illustration. The spare tire is for temporary use only (do not exceed 50 mph).

Jump Starting

The 12-Volt auxiliary battery may be jump started if the vehicle does not start and the instrument cluster gauges are dim or off after turning the ignition key to start.




- The 12-Volt auxiliary battery is located in the trunk. Follow the numbered sequence to connect the jumper cables as shown in the illustration.
- The high voltage HV battery pack cannot be jump started.

Alarm & Immobilizer

The vehicle comes standard with a keyless remote alarm and a coded key immobilizer system.

- The vehicle may only be started with a learned immobilizer coded key.

- To disable the alarm use the unlock button on the keyless remote, unlock either front door lock with the key, or turn the ignition switch on.



© 2001 Toyota Motor Corporation

All rights reserved. This book
may not be reproduced or copied,
in whole or in part, without the
written permission of Toyota Motor
Corporation

Printed in the United States of America
TMS M/N 00400-ERG02-0U

REV A (1/15/02)

